

"DEHUMID" COMBO




FIG. 1A

This Model based on the basic "DeHumid" Unit can during the winter months Humidify your home, by simply disconnecting the hose from the Outdoor exhaust and plug it into the floor Register.

The well known economical operation of the "DeHumid" is now further extended to supply you with a higher Comfort Index at minimum cost and actually lower your heating cost. (The Higher the Comfort Index, the lower the Temperature required.)

The Humidifier Section Consists of:

- A plastic tub equipped with a Float Valve.
- A plastic feed line from the water pipe.
- An outer case Housing.

The Section seats under the basic "DeHumid" and is held with 2 screws.





FIG. 1B

II

The "DEHUMID" Humidifier for the Winter Season



The Humidifier option forces the moistened air onto the main floor of the house during the winter months through the floor register.

The well known economical operation of the "Dehumid" is now further extended to supply you with a Higher Comfort Index at minimum cost and actually lower your heating cost. (The Higher the Comfort Index, the lower the temperature required.)

The Humidifier Section Consists of:

- A plastic tub equipped with a Float Valve.
- A plastic feed line from the water pipe.
- An economical circulating fan.
- A duct and floor register.



Unit Equipped with a Water Tray and Float Valve Control

FIG. 2